



Erao Micro Torque (Externally Adjustable) Screwdriver Operating Instructions



Calibrating Torque Screwdrivers


To calibrate torque screwdrivers either use a torque analyzer or torque transducer within the range of the torque screwdriver. For torque screwdrivers calibrate torque in "Peak" mode with an analyzer or transducer. Make sure to apply the torque slowly and smoothly.

1. Select a torque analyzer or transducer that covers the torque range of the EMT screwdriver. Connect screwdriver to the torque analyzer or transducer using the appropriate adapters as needed.
2. Apply torque clockwise slowly until screwdriver 'slips' and note reading.
3. Adjust screwdriver to required torque setting as described below.
4. Test and repeat adjustment as necessary to obtain desired value.
5. Recalibrate torque screwdriver at prescribed intervals.




Adjusting Torque Setting (During Calibration)

1. Insert hex key into hole located at end of rubber grip. (Note do-not attempt to remove rubber grip from the tool).
2. Turn hex key clockwise to increase torque and counter clockwise to decrease torque. Do not adjust torque above or below the recommended torque ranges.
3. Seal End Hole with Black RTV Sealant.



EMT 6, 9, 50 & 80 models are supplied with a T-Bar

1. Snap T-Bar into the slot located in the grip.



Setting and Applying Torque

1. Set desired torque on the scale. Pull down on the "Adjustment Ring" and turn handle clockwise to increase torque and counter clockwise to decrease torque on the scale. Align the desired torque value on the micrometer scale. Release "Adjustment Ring."
2. Tighten nut or bolt by applying steady twists. Screwdriver should be kept at 90 degrees to axis of bolt during tightening. When pre-set torque is reached, the screwdriver will 'slip.'
3. The screwdriver will automatically reset itself for the next application.
4. With its unique cam-over design, it's impossible to over tighten beyond the preset load.

